

Instruction



MODEL: 40SHB

USER'S MANUAL

MODEL: 40SHB

MODEL: 40SHB

NOTES

This manual provides information on the proper use and storage of the product and accessories, and assists the user in dealing with questions about their use and in understanding the safety precautions to be taken.

PLEASE READ CAREFULLY

When handing the product over to another person, be sure to include this manual, heed all warnings and follow all instructions in the manual.

2 YEAR WARRANTY DESCRIPTION

The warranty, which applies to all purchasers from our authorised dealers, covers any defects caused by production, as well as failures in the course of normal use, excluding physical damage, natural disasters (fire, flood, earthquake lightning, etc.) and chemical corrosion, unauthorised repairs, replacement of components during handling, collisions at the site of the installation and other failures due to human or force majeure reasons, and damage, or the manual. Any malfunction caused by acts expressly prohibited by the instruction manual.

ACCESSORY DESCRIPTION

Mobile phone clip, camera frame, hand screws and other accessories are consumables (not in the 2-year warranty), after use, please confirm whether there is aging, damage and other conditions of this phenomenon is normal wear and tear, in order to use the convenience of please contact the dealer in time to buy new parts replacement!


MAINTENANCE METHODS

Please use a soft sponge, soft cloth, dry cloth to clean the product regularly, do not use bleach, wire ball wipe, wipe clean and keep the product dry.

For more information on LENS GO product features, Please visit WWW.lensgo.net

1

INSTRUCTIONS



MODEL: 40SHB

OPERATING INSTRUCTIONS

Product structure diagram.

1 knob

Turn the knob clockwise to adjust the brightness of the light. Double-click the knob flash mode to enter the colour temperature mode

2 Flashing Button / Indicator Light

Press and hold to enter flash mode, release to pause the flash.

3 On/Off

Push the switch to ON position, automatically detect the power, the indicator light will run a circle and stop in the power position, if low power, please charge after use

4 DC charging port

Charging voltage 12V 2A

5 1/4 screw hole

Expandable mounting bracket with 1/4 thread connector

40SHB is a COB 40W, dual colour temperature 2700-7000K adjustable, colour rendering index >96, burst flash, along the vintage flash styling of the constant light, mobile phone / camera can be used!

2700K - 7000K DUAL COLOUR TEMPERATURE

Knob-adjustable infinitely dimmable, high display index to restore true colours

WITH SILICONE SOFTBOX

The soft light amplitude is suitable, the light is soft and not harsh

0%-100% BRIGHTNESS ADJUSTABLE


Turning the adjustment knob, the brightness change range is 0-100%

SPECIFICATION

MODEL:	40SHB
TYPE:	COB 40W
Colour temperature:	2700K-7000K
Jadette thumb ring:	≥ 96
Batteries:	4 x 18650 14.8V
Charging Voltage:	12V 2A
Duration of use:	Approx. 1 hour (when used at maximum brightness)
Adjustment range:	Brightness adjustment 0%-100%
Number of beads:	Total 192 pcs
Bead Voltage:	36 ~ 68V
Bead Current:	1100mA

4

INSTRUCTIONS



MODEL: 40SHB

Camera Usage

Mobile phone usage

Adjustable horizontal/vertical racket

1: Align the bracket to the bottom of the light first and tighten the screw by hand

2: The camera is set up on the bracket and screwed in by hand.

3: Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

WARNING

1: Align the bracket to the bottom of the light first and tighten the screw by hand

2: The camera is set up on the bracket and screwed in by hand.

3: Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

WARNING

8

9

LIST OF ACCESSORIES

You will receive the following accessories (subject to the options available at the time of your order)



1 Handheld light

2 Silicone softbox

3 Mobile phone clip (horizontal / vertical)

4 Battery charger

5 Camera bracket (mobile phone holder can be mounted)

6 Hand screw X2

MODEL: 40SHB

Please read these instructions carefully before using this product



WHEN USING, DO NOT SHINE THE LIGHT TO THE EYES TO PREVENT EYE BLURRING

2

3

tro

MODEL: 40SHB



ON / OFF

1 Push the switch to 'ON'.

Automatically detect the power after switching on, the indicator light will be red running around after the red light stops in the power position, low power when the red light flashes, please charge first after use

2 Long press to flash mode

Release to stop flashing

3 2700K-7000K colour temperature adjustment

Double-click the knob switch to enter the colour temperature mode, clockwise direction to adjust the cold light, counterclockwise direction to adjust the ambiguous light, adjust the completion of the double-click to return to the completion of the double-click to return to the 0-100% brightness adjustable

Push to switch between warm and cold light

Turn the knob clockwise to adjust the brightness of the light, this time the light will be in accordance with the % ratio of light, turn counterclockwise when the brightness is dimmed

When charging, press % to flash the light sequentially, full of red light always on

Charging time

FULLY CHARGED

BRACKET DESCRIPTION

1 1/4 screw hole, fits 5, locks bracket to light.

2 Expandable to mount any tripod device with 1/4 screws

3 With 6 hand screws, the camera can be mounted to the bracket with a locking mechanism.

4 Expandable to mount any tripod device with 1/4 screws

WARNING

Keep this product out of the reach of children in a safe place.

Please use the original parts correctly.

Before each use, please be sure to check whether the installation is stable, to prevent accidents during use.

Store in a cool, dry place, prohibit exposure to the sun, waterproof

6

7

INSTRUCTION



MODEL: 40SHB

WARNING

Do not touch the COB lamp beads with your hands to prevent burning hands

This product is a precision instrument, please avoid dropping it when using it.

Contact authorised service personnel when repairs are required

It is recommended to use the original LENS GO cables. Any damage to this product caused by the use of non-Longsong original accessories is not covered by our warranty. Any damage to this product is not covered by our warranty.

Please clean the product with a soft, dry cloth.

This specification is based on our rigorous testing. Design and specifications are subject to change without notice.

Please keep it in a safe place, read this instruction manual carefully, and observe all precautions

Before use, please check whether the installation is stable, to prevent accidents during use.

Please switch off the product after charging, in order to protect the safety and life of the battery, try not to use it during charging, use the product during charging.

Do not cover the ventilation holes when using the silicone softbox.

CERTIFICATE OF CONFORMITY

PRODUCT NAME::

MODEL:

INSPECTION DATE:

INSPECTOR:

QUALIFIED

10

11

LENS GO



MODEL: 40SHB

USER'S MANUAL

JIAZHUYING PHOTOGRAPHY EQUIPMENT CO., LTD.

Address: Room 201, Building C, No. 8 Fengqi Road, Fucheng'ao Community, Pinghu Subdistrict, Longgang District, Shenzhen, China

Web: <https://www.lensgo.net/>

Executive Standard: Q/LYJ004-2018

Facebook: Lensgotech

