

LENSGO

40SHC

USER'S MANUAL  
ヴァンテージ・ハンドヘルド・ランプ  
取扱説明書

MODEL: 40SHC

INSTRUCTIONS | NOTES

This manual provides information on the proper use and storage of the product and accessories, and assists the user in dealing with questions about their use and in understanding the safety precautions to be taken.

**PLEASE READ CAREFULLY**

When handing the product over to another person, be sure to include this manual, heed all warnings and follow all instructions in the manual.

**2 YEAR WARRANTY DESCRIPTION**

The warranty, which applies to all purchasers from our authorised dealers, covers any defects caused by production, as well as failures in the course of normal use, excluding physical damage, natural disasters (fire, flood, earthquake lightning, etc.) and chemical corrosion, unauthorised repairs, replacement of components during handling, collisions at the site of the installation and other failures due to human or force majeure reasons. and damage, or the manual Any malfunction caused by acts expressly prohibited by the instruction manual

**ACCESSORY DESCRIPTION**

Mobile phone clip, camera frame, hand screws and other accessories are consumables (not in the 2-year warranty), after use, please confirm whether there is aging, damage and other conditions of this phenomenon is normal wear and tear, in order to use the convenience of please contact the dealer in time to buy new parts replacement!

**MAINTENANCE METHODS**

Please use a soft sponge, soft cloth, dry cloth to clean the product regularly, do not use bleach, wire ball wipe, wipe clean and keep the product dry.

For more information on LENS GO product features, Please visit [WWW.lensgo.net](http://WWW.lensgo.net)

INSTRUCTIONS

40SHC is a COB 40W, dual colour temperature 2700-7000K adjustable, colour rendering index >96, burst flash, along the vintage flash styling of the constant light, mobile phone / camera can be used!

**● CREATIVE SCENE LIGHTING EFFECTS**  
Creating different personalised atmospheres to enhance the quality of the image shot

**● WITH SILICONE SOFTBOX**  
The soft light amplitude is suitable, the light is soft and not harsh

**● 0%-100% BRIGHTNESS ADJUSTABLE**  
Turning the adjustment knob, the brightness change range is 0-100%.

**COB 40W**

**SPECIFICATION**

MODEL:	40SHC
TYPE:	COB 40W
Charging port:	TYPE - C / DV
Jadeite thumb ring:	≥ 96
Batteries:	4 x 18650 14.8V
Charging Voltage:	12V 2A
Duration of use:	Approx. 1 hour (when used at maximum brightness)
Adjustment range:	Brightness adjustment 0%-100%
Number of beads:	Total 192 pcs
Bead Voltage:	36 ~ 68V
Bead Current:	1100mA

INSTRUCTIONS | BRACKET DESCRIPTION

**Camera Usage**

1 1/4 screw hole, fits 2, locks bracket to light.  
2 Expandable to mount any tripod device with 1/4 screws  
3 With 4 hand screws, the camera can be mounted to the bracket with a locking mechanism.  
4 Expandable to mount any tripod device with 1/4 screws

**WARNING**

- Keep this product out of the reach of children in a safe place.
- Please use the original parts correctly.
- Before each use, please be sure to check whether the installation is stable, to prevent accidents during use.
- Store in a cool, dry place, prohibit exposure to the sun, waterproof

LENSGO

If you have any questions, suggestions, or would like to share the wonderful works created with this light, please feel free to reach out to us through the channels below.

[www.lensgo.net](http://www.lensgo.net)

[@LensgoOfficial](#)

[Lensgotech](#)

[Lensgo.official](#)

LENSGO

**USER'S MANUAL**  
MODEL: 40SHC

**JIAZHIYING PHOTOGRAPHY EQUIPMENT CO., LTD.**  
Address: Room 201, Building C, No. 8 Fengqi Road, Fucheng'ao Community, Pinghu Subdistrict, Longgang District, Shenzhen, China  
Web: <https://www.lensgo.net/>  
Executive Standard: Q/LYJ004-2018  
[Facebook: Lensgotech](#)

**Made in China**

INSTRUCTIONS | LIST OF ACCESSORIES

You will receive the following accessories (subject to the options available at the time of your order)

**MODEL: 40SHC**

Please read these instructions carefully before using this product

**WHEN USING, DO NOT SHINE THE LIGHT TO THE EYES TO PREVENT EYE BLURRING**

1 Handheld light 2 Silicone softbox 3 Mobile phone clip (horizontal / vertical )  
4 Battery charger 5 Camera bracket (mobile phone holder can be mounted) 6 Hand screw X2

INSTRUCTIONS

**1: 0-100% brightness adjustable**  
Turn clockwise to adjust the brightness of the light, this time the indicator light will be in accordance with the % ratio of light, counterclockwise turn dimming brightness

**2: 8 lighting effects**  
Double click to enter FX mode

**3: Push to switch between warm and cold light**  
Click for instant switching

**4: Detecting power**  
Off state, click to detect the power, display the current power % position, if all do not light up, please charging

After switching on the device, the indicator lights are on blue, if the red light is flashing, please charge the device.

**FX MODE**  
8 different effects, press to switch, double click to exit after setting up

**LIGHTNING MODE TV MODE BAD BULB MODE**

**SOS MODE BURST MODE CANDLELIGHT MODE**

**PULSE FLASH MODE HIGH AND LOW BEAM BULBS**

When charging, flashing in order of %, full blue light always on

Charging Fully charged

INSTRUCTIONS | BRACKET DESCRIPTION

**Mobile phone usage**  
Adjustable horizontal/vertical racket

**WARNING**

- Align the bracket to the bottom of the light first and tighten the screw by hand
- The camera is set up on the bracket and screwed in by hand.
- Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

**WARNING**

- Do not touch the COB lamp beads with your hands to prevent burning hands
- This product is a precision instrument, please avoid dropping it when using it.
- Contact authorised service personnel when repairs are required
- It is recommended to use the original LENS GO cables. Any damage to this product caused by the use of non-Longsong original accessories is not covered by our warranty. Any damage to this product is not covered by our warranty.
- Please clean the product with a soft, dry cloth.
- This specification is based on our rigorous testing. Design and specifications are subject to change without notice
- Please keep it in a safe place, read this instruction manual carefully, and observe all precautions
- Before use, please check whether the installation is stable, to prevent accidents during use.
- Please switch off the product after charging, in order to protect the safety and life of the battery, try not to use it during charging. use the product during charging.
- Do not cover the ventilation holes when using the silicone softbox.

**CERTIFICATE OF CONFORMITY**

PRODUCT NAME: \_\_\_\_\_  
MODEL: \_\_\_\_\_  
INSPECTION DATE: \_\_\_\_\_  
INSPECTOR: \_\_\_\_\_

**QUALIFIED**